

FMI definition

FMI	Fault Description
FMI_0	Data valid but above normal operation range - most severe level
FMI_1	Data valid but below normal operation range - most severe level
FMI_2	Data erratic, intermittent or incorrect
FMI_3	Voltage above normal, or shorted to high source
FMI_4	Voltage below normal, or shorted to low source
FMI_5	Current below normal, or open circuit
FMI_6	Current above normal, or grounded circuit
FMI_7	Mechanical system not responding or out of adjustment
FMI_8	Abnormal frequency, pulse width, or period
FMI_9	Abnormal update rate
FMI_10	Abnormal rate of change
FMI_11	Root cause not known
FMI_12	Bad intelligent device or component
FMI_13	Out of calibration
FMI_14	Special instructions
FMI_15	Data valid, but above normal operating range - least severe level
FMI_16	Data valid, but above normal operating range - moderately severe level
FMI_17	Data valid, but above below operating range - least severe level
FMI_18	Data valid, but above below operating range - moderately severe level
FMI_19	Received network data in error
20 - 30	Reserved
FMI_31	Condition exists